


Instructions for Using a Style 24-1 Podium

If you need assistance with operating the system, please call the ITS Help Center at 456-8803. For more information about the podium style, scan the QR code below.



To begin class:

1. If the touch panel is dark, tap the screen to wake it up
2. Tap the screen where it says **Press HERE to begin**
3. Wait for the system to start up



During class:

1. Select a source using one of the four options at the top of the touch panel
 - For Blu-Ray, control the device with its remote inside the podium's drawer
 - For Doc Cam, control the device with its built-in controls or its remote
 - For Laptop, choose between a wired connection (HDMI) or wireless (ShareLink)
2. Turn the projector on or off with the buttons under "Display"
3. Turn the room's volume up or down or mute it with the buttons under "Program"



To end class:

1. Tap the **System Off** button
2. Tap the **Power Down** button to confirm

